

Cleaning and Care Instructions Homogeneous Vinyl Walling Sheet

Wallflex®, Accolade Plus®, Natralis®, Quantum®, Armalon NG®

Initial Care

1. After installation is completed allow 48 hours to dry.
2. Clean surface with a good quality pH 7.0 - 8.5 neutral cleaner.
3. Adhesive residue may be removed using a clean white cloth dampened with small amounts of mineral turps, carefully following warnings on container, immediately rinse with clean water (test in inconspicuous area first).

Routine Care

Clean surface with a good quality pH 7.0 - 8.5 neutral cleaner. Frequency of cleaning depends on environmental conditions and customer requirements.

Stain Removal

Treatment should be carried out when stains are fresh. Use a white or red hand pad in combination with a good quality pH 7.0 - 8.5 neutral cleaner. After stains have been removed wash/wipe with clean water. Spot cleaning/spot scrubbing would be conducted as necessary.

Protection During Construction

All vinyl walling materials must be protected during the construction period using a cardboard or paper based protection system.

Where additional or solid protection is required first install, cardboard or paper based protection system, and then rigid material over this (plywood, hardboard, corflute®, etc). Armstrong Flooring DOES NOT recommend the use of plastic materials for the protection of vinyl wall products during construction (e.g. builder's plastic, corflute®, sticky back carpet or vinyl protector or films), as these materials can damage the wall.

Surface protection must be applied over clean surfaces only.

DO NOT tape/stick protection directly to the wall. DO NOT allow water to sit on or under the protection materials (this could damage the wall materials and/or cause whitening/clouding of the surface which may be irreversible). Should the protection materials be exposed to water and become wet, the protection materials MUST be immediately removed.

Allow the surface to dry, then re-apply surface protection.

Warning & General Hints

1. Follow manufacturer's instructions for all cleaning chemicals.
2. Ensure the wall is protected from rubber (particularly black type) products such as tyres and mats as these can cause staining.
3. As with any vinyl walling, the use of improper cleaning agents and/or corrosive chemicals as acids, alkalis, caustic or solvent agents such as hydrochloric/sulfamic acid, pain stripper, benzene, toluol, acetone or strong scouring powders may damage floors.

AU: customerservices@armstrongflooring.au
NZ: customerservices@armstrongflooring.co.nz